

DVICED

Car charger 60W 1 USB-A, 2 USB-C User Manual



Thank you for choosing us

We value your trust. We hope that you will be happy with our product, and as excited about it as we are. We try to offer products of the highest quality that satisfy even the most demanding requirements. If you are satisfied, it would make us very happy if you chose us again the next time you make a purchase.

Technical specifications

- Input voltage: 12-24V
- Max. output power: 48W
- USB·C output power: 5V/3A; 9V/2.77A; 12V/2.5A; 15V/2A; 20V/1.5A
- USB-A output power: 5V/2.4A; 9V/2A; 12V/1.5A
- Maximum input current: 5A
- Output voltage stability: ≤0.1 V
- Supported fast charging standards: PPS, PD3.0, PD2.0, QC3.0, QC2.0, AFC, FCP, BC1.2, DCP, Apple2.4A etc.
- Dimensions: 60x25x 25mm
- Weight: 60g

Overview



- 1. USB-A connector: Connector for connecting a USB-A charging cable
- 2. Plug for cigarette lighter socket
- 3. USB-C connector: Connector for connecting a USB-C charging cable

Use

- 1. Plug the adapter into a socket in your car.
- 2. Connect the device you want to charge using a USB cable. USB cable is not included.
- 3. Once the device is charged, first disconnect the USB cable and then unplug the adapter from the power outlet.
- 4. Always unplug the adaptor from the socket when not in use.

Safety information

• Please check compatibility with the information specified on the product before use.

• This product is not a toy. It may contain small components. Please keep away from children.

• Do not use the product to charge devices that require a charging current greater than that specified in the technical specification. Once your device is fully charged, disconnect it from the product

• Unplug the product from the cigarette lighter socket when not in use

EN DVICED

• Only use the product for its intended purpose

• It is forbidden to handle the product as well as the inserted phone while driving. Pay full attention to driving.

• Incorrect use of the product can lead to a risk of fire, explosion or other hazard and can result in a voided warranty.

• Do not use or leave the product in dusty or otherwise contaminated environments.

• Do not expose the product to extreme temperatures, direct sunlight, heat sources, etc. Avoid contact with open flame. Do not place open flame sources, such as lit candles, on the product. Keep the product in a dry environment.

• Do not expose the product to dripping or splashing water. Do not place water containers, such as vases, on the product.

• Do not place heavy objects on the product. Do not subject it to shocks, falls or other mechanical damage

• Do not disassemble the product. Attempting to modify the product may damage it and result in serious injury

• Do not use the product if it is damaged or emits an unusual odour.

• Use only a soft, clean, dry cloth to clean the surface. Do not use harsh or chemical cleaners, petrol, thinners, etc.